



- | | | | |
|---|---|----|-----------------------------------|
| 1 | QUICK-CONNECT FITTING
(FUEL FEED HOSE) | 8 | LOCKING TABS |
| 2 | ROLL-OVER VALVE | 9 | FUEL PUMP STRAINER |
| 3 | VENT HOSE RETAINER | 10 | FUEL SENDER ASSEMBLY |
| 4 | VENT HOSE | 11 | FLOAT |
| 5 | SENSOR | 12 | FLOAT ARM |
| 6 | FUEL SENDER | 13 | FUEL PUMP &
RESERVOIR ASSEMBLY |
| 7 | BUMPER | 14 | FUEL RETURN HOSE |